



Table of use and measurements

Height (cm) Pegasus Basic	No. of profiles										No. of crosses																				
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20											
193,8	202	10	31	22	52	33	73	44	94	55	66	115	66	136	77	157	88	178	99	110	199	220	241	132	262	143	283	304	165	325	176
174,6	182	9	28	47	30	66	40	85	50	60	104	50	123	70	142	80	161	90	180	110	199	218	237	130	256	140	275	150	294	160	
155,4	162	8	25	42	27	59	36	76	45	54	93	45	110	63	127	72	144	81	161	99	178	195	212	117	229	126	246	135	263	144	
136,2	142	7	22	37	24	52	32	67	40	48	82	40	97	56	112	64	127	72	142	80	157	172	187	104	202	112	217	120	232	128	
117	122	6	19	32	21	45	28	58	35	42	71	35	84	49	97	56	110	70	123	80	136	149	162	91	175	98	188	105	201	112	
97,8	102	5	16	27	18	38	24	49	30	36	60	30	71	42	82	48	93	54	104	66	115	126	137	78	148	84	159	90	170	96	
78,6	82	4	13	22	15	31	20	40	25	30	49	30	58	35	67	40	76	45	85	50	94	103	112	65	121	70	130	75	139	80	
59,4	62	3	10	17	12	24	16	31	20	24	38	24	45	28	52	32	59	36	66	40	73	80	87	52	94	56	101	60	108	64	
40,2	42	2	7	12	9	17	12	22	15	18	27	18	32	21	37	24	42	27	47	30	52	57	62	39	67	42	72	45	77	48	
21	22	1	4	7	6	10	8	13	10	12	16	10	19	14	22	16	25	18	28	20	31	34	37	26	40	28	43	30	46	32	
Length (cm)	Basic		22	42	62	82	102	122	142	162	182	202	222	242	262	282	302	322	342	362	382	402	422	442	462	482	502	522	542	562	582
	Pegasus	21	40,2	59,4	78,6	97,8	117	136,2	155,4	174,6	193,8	213	232,2	251,4	270,6	289,8	308,4	327,0	345,6	364,2	382,8	401,4	420,0	438,6	457,2	475,8	494,4	513,0	531,6	550,2	568,8

NB For larger surfaces specific structural calculations are needed.
VetroQUICK is suggested for interior applications.

Seves S.p.A.

Administration, Offices, Factories, Warehouses
Via R. Giuliani, 360 - 50141 Firenze - Italia
Tel.: +39 055 449 51 - Fax: +39 055 425 009 6
Sales Dept. Fax: +39 055 455 295
www.sevesglassblock.com

SEVES



VetroQUICK


installation system
simple, quick, safe

SEVES
GLASS
BLOCK

VetroQUICK is a dry installation system for creating glass block walls simply, quickly, safely and simplifies installation with the use of a few accessories: a profile and a cross.

Accessories:

prepare the cross to insert in different parts of the wall;




- "L" cross: to be used at the corners of the wall
- "T" cross: to be used on the perimeter of the wall (accept the corners of the wall)
- "+" cross: to be used between the glass blocks (accept the perimeter and the corners)



Profile to use with to intersect 2 walls with a 90° angle

DESIGN LINE

BASIC LINE



- "L" cross
- "T" cross
- "+" cross

No. of crosses needed per m2: 36 pcs.
No. of profiles needed per m2: 60 pcs.

Installation:

IMPORTANT: before starting the installation process:

Mark with a pencil the dimensions of the glass block wall on the floor and wall, making sure that these lines are square and level. If the wall is created with a wooden profile or another type of material, make sure the profile is securely fastened to the floor and wall.

Installation process

Prepare the cross as "L" shape (for the starting angle) or "T" shape (for the first row of blocks) If creating cantilever walls (or using the end of a wall).

Cut the profile in correspondence of the score line that marks the end block of the wall or rectangular block.

Use the cross depending on the glass block chosen (Pegasus or Basic) Prepare the cross as "L" shape and, use the profiles to insert it into the appropriate slot until a right angle is formed.

Draw the necessary points on the floor and wall next to the holes present on the profile. Drill the holes. Place the wedges and screw the structure to the square created beforehand with VetroQUICK.

Prepare the cross as "T" shape and join it to the profiles. Continue to add profiles and crosses, repeating the drawing, drilling and screwing operations until reaching the desired width of the wall.

Once all the horizontal profiles have been positioned, start inserting the vertical profiles by inserting them into the slits.

Place the glass blocks in between the vertical profiles until the row is completed

Insert a "T" shape cross into the top block leaning against the wall (laterally) in order to continue the installation process with VetroQUICK

Add more rows of VetroQUICK accessories and glass block rows until the whole wall is completed.

Finishing process

Finish off the joints with quick-setting mortar.

Mix the special mortar (cement-based filler) with the suitable mixing spade on the adjustable speed,

Apply it with the suitable spatula or gummy plastering trowels.

- Fill the joints with the special mortar of the desired colour.
- Sponge the joint area after it has hardened.

Clean with a wet cloth the surface of the glass when the mortar is dry but still not hardened, and refine your work with the suitable products.

VetroQUICK is conceived and developed for indoor use.

However it can be used in settings subject to high humidity or exposure to water (e.g. shower stalls) if totally impermeable finishing for joints is used, and if the finishing is done in a workman-like manner.


To our knowledge, the information in this technical leaflet is accurate and reliable.

Since Seves SpA does not have any means of controlling installation and assembly conditions, of whether competent persons do to work or the appropriate selection and correct use of the accessory materials, no guarantee can cover materials that prove defective after installation and/or assembly.

For detailed information, please contact the technical dept.



make sure that the base laid perfectly flat, in case use the suitable shims (wooden edges or pieces). it is important that the wall is perfectly horizontal and vertical.




Prepare the crosses and join them to the profiles. Continue to add profiles and crosses, repeating drawing, drilling and screwing operations until reaching the desired width of the wall



Place the glass blocks in between the vertical profiles.



Add more rows of vetroQUICK accessories and glass block rows until the whole wall is completed.



finish the joint with quick-setting mortar



make cleaning of the wall

For further information and the video of accessories and installation, please visit www.vetroquick.com or www.sevesglassblock.com

CZECH REPUBLIC
SKLOBETON s.r.o. Zenklova 1171/4, 180 00 Praha, Libeň
Phone: +420 603 547 262 E-mail: info@sklobetonsro.cz
Eshop: www.sklobetonsro.cz